

VACUUM PUMP LUBRICANT INSTRUCTION



- 1 Remove lower bracket and take out the piston rod.
- 2 Clean the piston. Do not disassemble the piston.
- 3 Apply a layer of new lubricant to the outer surface of the piston.
- 4 Carefully insert the piston rod and refit the bracket.
- 5 After service always perform a vacuum test
- 6 Install the safety seal to prevent un-authorized activation.

Lubricate piston every second year.

Always use lubricant approved by CM Hammar - Art. no HM-0334 Lubricant TP55.

Do not disassemble the non-return valve in the end part. If the failure continue, a new complete part should be ordered.

If the vacuum pump does not hold the vacuum after lubrication service is done disassemble the stainless steel tubing and make sure that no dirt or burr is affecting the air flow.